



# STEP BY STEP DEPLOYMENT INSTRUCTIONS

Thank you for your recent purchase of one of the most unique and carefully crafted covers. It is designed for those who want to protect their items from rodents, weather, heat and sun damage. Here are some helpful tips on using your new cover.



## Deployment:

1. Take cover out of provided duffel bag. Unroll the cover with the weighted apron closest to your patio or grill.
2. Starting on the side the cover is unrolled, begin deployment. Raise the weighted edge and begin to cover your patio or grill.
3. Walk around your patio or grill and continue to lift the cover utilizing the weighted bottom to help drop to the opposite side.
4. Finish deployment by walking around your patio/grill 360° Degrees to confirm the weighted apron is resting on the ground evenly.

## Duffel Bag Storage Tips:

1. Remove cover fold in half so weighted bottom from each half are almost touching.
2. Fold in silver material as tight as possible.
3. Start rolling up one end of the cover stopping at the middle.
4. Roll the opposite side stopping in the middle.
5. Completely open duffel and insert rolled cover.

**Weather protection:** CoverSeal material is durable and breathable. It reflects 90% of the sun's damaging rays. The covers are made intentionally loose. The loose fit keeps precipitation from puddling on the cover leading to mold.

**Use and cleaning your cover:** Be cautious of sharp edges on patio/grill avoiding damage to cover. Stains and dirt can simply be wiped-off your cover with a damp towel.

**Fixing a damaged cover:** In the slight chance your cover gets caught on a sharp edge and a small tear occurs, it's important to stop any rip quickly. In the event this happens, we have found using silver (for the cover) or black (for the apron) heavy duty tape can extend the life of the cover by stopping the rip. Use a strip of heavy duty tape roughly 1/2 inch longer than the tear on the inside and another on the outside of the cover to create a patch. Forming a double-sided patch will eliminate adhesive from touching your outdoor investment.

### CAUTION:

ONLY use for covering outdoor patio furniture or grill. Remove cover completely before turning appliance "on" or putting in start mode. Turn "off" before recovering

[www.getcoverseal.com](http://www.getcoverseal.com) | [support@getcoverseal.com](mailto:support@getcoverseal.com)  
CALL US! 669.208.2601