



STEP BY STEP DEPLOYMENT INSTRUCTIONS

Thank you for your recent purchase of one of the most unique and carefully crafted covers. It is designed for those who want to protect their items from rodents, weather, heat and sun damage. Here are some helpful tips on using your new cover.

Weather protection: CoverSeal material is durable and breathable. It reflects 90% of the sun's damaging rays. The covers are made intentionally loose. The loose fit keeps precipitation from puddling on the cover leading to mold.

Use and cleaning your cover: Dirt from loose gravel driveways/carports can simply be wiped-off your cover with a towel before and after deployment.

Fixing a damaged cover: In the slight chance your cover gets caught on a sharp edge and a small tear occurs, it's important to stop any rip quickly. In the event this happens, we have found using silver (for the cover) or black (for the apron) heavy duty tape can extend the life of the cover by stopping the rip. Use a strip of heavy duty tape roughly 1/2 inch longer than the tear on the inside and another on the outside of the cover to create a patch. Forming a double-sided patch will eliminate adhesive from touching your vehicle.



Deployment:

1. Roll out the cover next to the passenger side of the truck with the silver side facing up.
2. Starting from the back lift the cover onto the truck bed and walking forward put most of the edge of the weight into the truck bed.
3. Drape the edge of the cover over the side mirror.
4. Continue walking forward and put it on the hood and over the top of the hood.
5. Locate pull over straps and throw them over the top of the truck.
6. Pull the straps to get more of the edge of the cover onto the roof of the truck. Please make sure the antenna is not in the way (some trucks need to unscrew and remove).

NOTE: If the edge is not lifting over the roof see if you need more weighted apron in the bed of the truck or on the hood. Once you get the weighted edge moving onto the roof the cover should easily pull over. Even the cover around the vehicle and tuck the pull straps under the cover. Check 360 degrees around vehicle to check bottom of the cover is resting completely on the ground

To get the cover off using the zipper feature:

1. Split the hook/loop in the back under the logo.
2. Unzip the zipper starting from the back and moving to the front.
3. Remove the body of the cover from the edge weight, go to the passenger side and pull the cover off the vehicle.
4. Split the back end of the cover wide enough to back the vehicle out. Repeat the process in reverse to put the cover back on.

Deployment - NO weight method (Start with zipper feature):

1. Place the cover onto the ground or driveway where you want to park the truck. Make sure the silver side is up and FRONT is where there FRONT of the vehicle will be.
2. Stretch the side of the cover as wide as you can.
3. Split the back of the hook/loop under the logo on the apron and unzip the cover all the way.
4. Pull the cover to the passenger side.
5. Split the apron wide enough to pull in the truck.
6. Drive into the cover as far as you can without running over the apron.
7. Pull the cover over the vehicle.
8. Zip the cover all the way around to the back of the apron and reconnect the Hook/Loop so a seal is formed.
9. It might be necessary to pull the cover further back toward the tailgate if it is not evenly placed on the truck and the seal in the rear cannot be connected.

CAUTION:

ONLY use for covering vehicles.
Remove cover completely before turning vehicle "on" or putting in start mode. Turn "off" before recovering.